

SERVICE KIT: #70

DATE: January 25, 2007

EFFECTIVITY: Air Tractor AT-802A S/N

COMPLIANCE: As soon as possible, if hydraulic solenoid valve in scooping system is sticking.

BACKGROUND INFORMATION: Contaminants in hydraulic fluid may cause the directional solenoid valve to stick.

METHOD OF COMPLIANCE: Add additional filters (2) at solenoid valve inlets for additional filtration.

Replace (2) existing filter elements with a finer mesh 10 micron element.

PARTS REQUIRED:


		· ·	
<u>Item</u>	<u>Quantity</u>	Part Number	Description
10	2	9053-10	Filter
20	2	EK9052-10	Filter Element
30	1	1002117	Spacer
40	4	AN4-13A	Bolt
50	4	NAS1149D0-463J	Washer
60	4	MS21044-N4	Nut
70	2	AN911-3D	Nipple
80	2	AN912-1D	Reducer
90	2	AN912-2D	Reducer
100	2	MS20826-5D	"T" Fitting
			6

WARRANTY: Parts only

Instructions:

- 1. Unbolt solenoid valve from plate (4) .25 DIA bolts.
- 2. Unhook hydraulic lines on left and right side of manifold block. Identify for reinstall.
- 3. Remove manifold blocks from plate and detach from solenoid valve.
- 4. Add 1002117 spacer to between the plate and solenoid valve. Attach with (4) AN4-13A bolts, NAS1149D0-463J washers, and MS21044-N4 nut.
- 5. Install 9053-10 filter on each side of solenoid valve as shown. Attach with AN911-3D nipple.
- 6. Install AN826-5D "T" fittings to filters as shown using AN912-1D reducer and AN912-2D reducer. Position fitting as shown.
- 7. Reattach all hydraulic lines as shown.
- 8. Replace filter elements in existing 2 filters housings with EK9052-10 filter elements.
- 9. If fluid appears red in color, the tanks of the hydraulic pump should be removed and filters in pickup cleaned and any residue removed from tank bottom.
- 10. It is recommended to change fluid in the entire hydraulic system if fluid seems contaminated or dark in color.

REAR VIEW HYDRAULIC PUMP



SIDE VIEW

