

WIPAIRE, INC.
INVER GROVE HEIGHTS, MN

DATE: April 6, 2004

SERVICE KIT: #44

SUBJECT: Addition of vent ball stop

MODEL: Fire Boss AT-802A

<u>Item</u>	<u>Quantity</u>	<u>Part No.</u>	<u>Description</u>
1.	1	AN526C1032R18	Screw
2.	1	NAS1149CO363R	Washer
3.	1	MS21044C3	Nut
4.	1		Bumper
5.	1	#63	Service Letter

INSTRUCTIONS:

1. Drill #10 (.193) diameter thru 1 wall of vent ball cage, 3.63 up from lower edge as shown on below drawing.
2. Install screw, washer, nut, and bumper as shown.

