SERVICE LETTER 270

LANDPLANE STEP REMOVAL

Aircraft Makes/Model(s):	rcraft Makes/Model(s): Float Model(s):		Aircraft Makes/Model(s): Float Model(s): Cor		By: MAS
Air Tractor	10000A	Part Number: 1012727	Approved:DRH		
AT-802A & AT-802	10000A	Date: 2/6/2025	Revision: A		

LOG OF REVISIONS

Revision	Description	
A	Initial release	2/6/2025

FAA approval has been obtained for technical data in this publication that affects STC or TSO design compliance.

EFFECTIVITY:

This service letter applies to Air Tractor AT-802 and AT-802A model aircraft with Wipline 10000 amphibian floats installed per STC SA01795CH.

COMPLIANCE:

Compliance is optional.

BACKGROUND:

For purposes of weight and balance it may be beneficial to remove the fuselage boarding steps. The usefulness of these steps is partially negated when floats are installed.

COMPLIANCE METHOD:

If desirable for operations, remove fuselage boarding steps and modify panels by following the "Work Instruction" section of this letter.

APPROXIMATE SHOP HOURS:

Performing the work instructions will take approximately 4 labor hours to complete.

WEIGHT AND BALANCE:

DESCRIPTION	WEIGHT	ARM
REMOVE FUSELAGE BOARDING STEP L+R AND INSTALL COVER PLATES	-21.00 LB	92.00 IN

WARRANTY INFORMATION:

This service letter does not include warranty for labor or parts.

TECHNICAL DATA:

Copies of this service letter, associated service kit (if applicable), float service manual, and float parts manual are available at www.wipaire.com.



ITEMS PROVIDED IN SERVICE KIT 1012727-01 (1 KIT PER AIRCRAFT)			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	1012304	BACKER, COVER, STEP, LH, AT802/AT802A
2	1	1012305	BACKER, COVER, STEP, RH, AT802/AT802A
3	1	1012306	COVER, STEP, LH, AT802/AT802A
4	1	1012307	COVER, STEP, RH, AT802/AT802A

Work Instructions

1. Position and prepare aircraft for safe maintenance.

NOTE: Refer to Figure 1 while performing the following steps.

- 2. Remove aircraft panels at fuselage step locations
- 3. Remove Air Tractor fuselage steps
- 4. Test fit kit items to the removed aircraft panels as shown, trim to fit as needed.
- 5. Lay out (10) rivet holes around edges of LH and RH cover backers (items 1 and 2) as shown.
- 6. Match drill the holes placed in previous step through aircraft panels.
- 7. Seal and rivet cover pieces to backers (item 1 to item 3, item 2 to item 4) using MS20426-4 rivets, flush on outside.
- 8. Fasten combined pieces from previous step to aircraft panels using MS20426-4 rivets. Double flush rivets in areas that will contact edge gasket used at quarter turn fasteners.

OPTIONAL: Nutplates may be used in place of rivets where there is no conflict with edge gaskets. Nutplates to be MS21059-L08, screws to be MS24693-S49 (not provided in kit).

- 9. Paint panels as needed.
- 10. Reinstall aircraft panels.






FIGURE 1

Aircraft Closing & Return to Service

Upon completion of inspection, enter information in Aircraft Logbook for completion of Wipaire Service Letter 270.