



# Ski Sub-Assembly and Parts

Wipaire Parts Sales Team:

**1.888.947.2473**

WIPLINE FLOATS - SKIS - MODIFICATIONS

Direct: 1.888.947.2473 | Fax: 651.451.1786 | [www.wipaire.com](http://www.wipaire.com)  
1700 Henry Avenue South - Fleming Field (KSGS) South St. Paul, MN 55075

Part Number	Part Description	Unit of Measure
0249-5151	Cord, Shock 3/8 "	FT
06-12200	Cord, Shock 1/4"	FT
06-12800	Fastener, Shock Cord 1/4", Spring 3/4"	EA
1003492	Ass'y, Ski Hand Pump	EA
10A1059	Brace	EA
10A1062	Skag	EA
10A1071	Fitting - Modified	EA
10A1075	Bushing	EA
10A1150	Tube	EA
10A1248	Spacer Bushing	EA
10A1249	Bushing	EA
10A1262	Axle Shaft	EA
10A1263	Spacer	EA
10A1267	Spacer	EA
10A1277	Bracket	EA
10A1404-1	Brace Bottom Stiff	EA
10A1404-2	Brace Bottom Stiff	EA
10A1410	Pull-Off	EA
10A1412	Bracket	EA
10A1428	Threaded Plug	EA
10A1432	Valve Handle Drilled	EA
10A1444	Plate Attach	EA
10A1505	Lug	EA
10A1528	Gusset	EA
10A1620	Flange Tube	EA
10A1626	Bushing	EA
10A1628	Spacer/Washer	EA
10A1643	Fitting	EA
10A1643-2	Fitting	EA
10A1644	Collar	EA
10A1645	Collar	EA
10A1647	Spring	EA
10A1676	10A1676	EA
10A1683	Rigger Bracket	EA
10A1690-1	Side Plate	EA
10A1690-2	Side Plate	EA
10A1691	Lugs	EA
10A1824	Bushing	EA
10A1882	Bushing	EA
10A1883	Bushing	EA
10A1886	Bushing	EA
10A1887	Sideplates	EA
10A1889	Gusset	EA
10A1903-1	Arm	EA
10A1903-2	Arm	EA
10A1904	Axle T.S.	EA
10A1906-1	Bushing/spacer	EA
10A1906-2	Bushing/spacer	EA
10A1925-1	Bracket	EA
10A1959	Stiffener	EA
10A1960	Bumper Pad	EA
10A2004	Lug	EA

Part Number	Part Description	Unit of Measure
10A2005-1	Plate	EA
10A2028	Bushing	EA
10A2030	Chamfer Tube	EA
10A2031	Chamfer Tube	EA
10A2046	Washer	EA
10A2048	Gusset	EA
10A2060	Washer	EA
10A2061	Flange Spacer	EA
10A2063	Handle	EA
10A2076	Spacer	EA
10A2077	Stud - Cyl. Mod	EA
10A2081	Bushing	EA
10A2090	Bottom Flange	EA
10A2091	Top Flange	EA
10A2092	Tube	EA
10A2098	Boss	EA
10A2099	Boss Assy.	EA
10A2100	Tube	EA
10A2101	Filler Cap Reservoir	EA
10A2107	Bracket	EA
10A2111	Plate	EA
10A2116	Bracket	EA
10A2126	Clamp	EA
10A2128	Angle	EA
10A2129	Angle	EA
10A2139	Gusset	EA
10A2141	Bracket	EA
10A2142	Bracket	EA
10A2143	Gusset	EA
10A2144-1	Bushing	EA
10A2144-2	Bushing	EA
10A2145	Stud Long	EA
10A2146	Bumper	EA
10A2175	Spacer	EA
10A219-1	Spacer	EA
10A2200	Bushing	EA
10A2201	Spacer	EA
10A2203	Fitting	EA
10A2214	Handle	EA
10A2219	Bushing	EA
10A2222	Pad	EA
10A2239	Lug	EA
10A2240	Box Assy.	EA
10A2242	End Plate	EA
10A2243	End Plate	EA
10A2244	Cover	EA
10A2246	Union	EA
10A2251-5	Valve	EA
10A2290-2	Reducer Bushing	EA
10A2339	Cable - Bracket Assy	EA
10A2340	Plate	EA
10A2341	Loop Attachment	EA

Part Number	Part Description	Unit of Measure
10A2356	Bushing	EA
10A2357	Bushing	EA
10A2378	Washer	EA
10A2426	Shim - Relief Valve	EA
10A2470-1	Gusset	EA
10A2470-2	Gusset	EA
10A2475	Lug	EA
10A2476-1	Spacer	EA
10A2482	Plate	EA
10A2581	Fitting	EA
10A2583	Arm	EA
10A2586-1	Gusset	EA
10A2600	Arm Plate	EA
10A2602	Plate	EA
10A2603	Bracket	EA
10A2628	Spacer	EA
10A2681	Bushing	EA
10A2699	Bushing	EA
10A2935-1	Bracket	EA
10A2935-2	Bracket	EA
10A2973	Handle	EA
10A2977	Retainer Scraper Ring	EA
10A2995	Rod	EA
10A2996	Washer-Retaining Arm & Bellcrank	EA
10A2999	Block, Cable Aft	EA
10A3126	Washer	EA
10A3127	Spacer	EA
10A3194	10A3194	EA
10A3207	Bearing	EA
10A3221	Bracket	EA
10A3296	Aft Bumper	EA
10A3343	Bracket	EA
10A3356	Bracket Assembly, Formed	EA
10A3357	Lug	EA
10A3359	Decal	EA
10A3359-2	Placard/ decal	EA
10A3365	Bracket	EA
10A3366	Lug	EA
10A3368	Spacer	EA
10A3372	Clamp, Hose	EA
10A3374	Skag, 3200 ski	EA
10A3379	Runner	EA
10A3380	Washer, Thrust	EA
10A3387	Strip, Binder	EA
10A3390	Binder Strip	EA
10A3391	Binder Strip	EA
10A3393	Strip, Binder-Short Side	EA
10A3395	Strip, Binder	EA
10A3397-2	Strip, Binder Long	EA
10A3432	Lug	EA
10A3434	Bracket	EA
10A3462	Lug	EA

Part Number	Part Description	Unit of Measure
10A3487	Lug	EA
10A3491	Spacer Tube	EA
10A3492	Axle Rod- Do Not Buy Use AN4-50A	EA
10A3498	Lug	EA
10A3515	Binder Strip	EA
10A3524	Spacer	EA
10A3571-1	Cylinder-Pin	EA
10A3571-2	Cylinder-Pin	EA
10A3571-3	Pin	EA
10A3571-4	Tab	EA
10A3602-1	Stop, Aft Back Plate	EA
10A3602-2	Stop, Aft Back Plate	EA
10A3616	Clip Fairing	EA
10A3630	Bracket	EA
10A3654	Bushing	EA
10A3669	Piston Rod	EA
10A3794	Lug	EA
10A3823	Lug, Inner	EA
10A3824	Lug, Outer	EA
10A3825	Angle, Bracket	EA
10A3826	Plate, Bracket	EA
10A3829	Lug, Inner Atlee Dodge 1 1/4" Axle	EA
10A3830	Lug, Outer Atlee Dodge 1 1/4" Axle	EA
10A3831	Lug, Inner, Atlee Dodge 1 1/2" Axle	EA
10A3832	Lug, Outer, Atlee Dodge 1 1/2" Axle	EA
10A3833	Lug, Outer Univair 1 1/2" Axle	EA
10A3835	Lug, Inner Univair 1 1/2" Axle	EA
10B1025	Plate	EA
10B1079-1	Valve	EA
10B1087-2	Bushing	EA
10B1195	Plate	EA
10B1383	Pedestal Plate	EA
10B1632-1	Fitting	EA
10B1632-2	Fitting	EA
10B1638-1	Bracket	EA
10B1640	Clamp	EA
10B1640-1	Clamp	EA
10B1641	Clamp	EA
10B1641-1	Clamp	EA
10B1642	Clamp	EA
10B1665-1	Axle	EA
10B1665-2	Axle	EA
10B1689	Strip	EA
10B1868	Axle	EA
10B1980	Side Plate	EA
10B1982	Reinforcement	EA
10B1983-3	Plate - Front	EA
10B2037	Piston Rod End	EA
10B2039	Gusset	EA
10B2039-1	Plate	EA
10B2039-2	Gusset	EA
10B2040	Bracket Assy.	EA

Part Number	Part Description	Unit of Measure
10B2053	Plate	EA
10B2054	Strap	EA
10B2064	Cover	EA
10B2088	End Plate	EA
10B2089-1	U - Section	EA
10B2089-2	U - Section	EA
10B2097	Bracket	EA
10B2106-1	Angle	EA
10B2106-2	Angle	EA
10B2118	ID Plate	EA
10B2124	Bracket - Hold Down	EA
10B2140	10B2140	EA
10B2194-1	Bracket	EA
10B2195-1	Bracket	EA
10B2198	AT 3500 A (Saddle)	EA
10B2237	Bracket Assy.	EA
10B2424	Channel	EA
10B2447-1	Bracket	EA
10B2447-2	Bracket	EA
10B2452	Plate	EA
10B2454	Runner	EA
10B2627-1	Plate	EA
10B2627-2	Plate	EA
10B2673-1	Pin Cylinder, L.H.	EA
10B2673-2	Pin Cylinder, R.H.	EA
10B2673-3	Rod	EA
10B2683	Bellcrank	EA
10B2934-1	Bracket Assy	EA
10B2934-2	Bracket Assy	EA
10B2934-3	Bracket Assy	EA
10B2950	Piston Cylinder	EA
10B2972	Angle - Base	EA
10B2976	End Cap	EA
10B2990-3	Pivot Shaft	EA
10B2991	Liner	EA
10B2994-1	Stop	EA
10B2994-2	Stop, Mod.	EA
10B2997	Pedestal, Ski	EA
10B2998	Cylinder, Rod DO NOT USE, USE 10B3819	EA
10B3008	Outer Ring	EA
10B3015	Rod End Assy	EA
10B3340-5	Clamp	EA
10B3347	Axle Extension	EA
10B3349-1	Pedestal Assembly, Lt.	EA
10B3353	Doubler	EA
10B3354	Anchor, Cylinder (machined)	EA
10B3361	Runner (C2200)	EA
10B3362	Runner (C3200)	EA
10B3407	Arm Assy	EA
10B3427	Runner	EA
10B3481-1	Bar	EA
10B3481-2	Bar	EA

Part Number	Part Description	Unit of Measure
10B3490	Side Plate	EA
10B3497-1	Pedestal Side Plate	EA
10B3525-3	Cylinder, Barrel	EA
10B3542-1	Cly End	EA
10B3545	Pivot Shaft	EA
10B3548	Cable Block	EA
10B3567-1	Brace & Stop Casting	EA
10B3567-2	Brace & Stop Casting	EA
10B3569-1	Stop	EA
10B3569-2	Stop	EA
10B3597-1	Reinforcement, forward	EA
10B3597-3	Reinforcement, aft	EA
10B3605	Bellcrank	EA
10B3607	Rod, Piston	EA
10B3609	End Cap Cylinder	EA
10B3619-1	Angle - Fairing	EA
10B3619-2	Angle - Fairing	EA
10B3645-2	Plate	EA
10B3650-7	Bracket, Rigger	EA
10B3650-8	Bracket	EA
10B3764	Decal	EA
10B3768-1	Bracket, pump mount (L.H.)	EA
10B3768-2	Bracket, pump mount (R.H.)	EA
10B3774	Ring	EA
10B3776	Washer	EA
10B3780	Elbow - Modified	EA
10B3782	Rod Cylinder	EA
10B3785	10B3785	EA
10B3787	Spacer	EA
10B3793	Block	EA
10B3798-1	Handle	EA
10B3798-2	Handle	EA
10B3799	Bracket	EA
10B3804	Bushing	EA
10B3808-1	Reducer	EA
10B3808-5	Adaptor Assy	EA
10B3808-6	Ball Valve Ext	EA
10B3812	Stop, C3000A	EA
10B3812-1	Stop - Long Assy	EA
10B3812-3	Bolt Plate	EA
10B3812-4	Stop - Short Assy	EA
10B3817	Cover, Gear Control Round	EA
10B3818	Cover, Gear Control Rectangular	EA
10B3819	Cylinder-Rod	EA
10B973	Reinforcement	EA
10B976-1	Plate	EA
10B976-2	Reinforcement	EA
10C165	Ski Bottom	EA
10D1193-1	Bent Plate	EA
10D1193-2	Bent Plate	EA
10D1408-1	Side Plate	EA
10D160	Bottom, A3500A	EA

Part Number	Part Description	Unit of Measure
10D1677	Arm	EA
10D2026	Saddle	EA
10D2067	Gusset	EA
10D2087	Stop Bracket Assy.	EA
10D2094-1	Shell	EA
10D2095	Reservoir - Shell	EA
10D2102-4	Plate	EA
10D2103-29	Hand Pump & Relief Valve Assy.	EA
10D2117-13	Spacer	EA
10D2199-1	Saddle	EA
10D2210	Valve	EA
10D2232-18	Valve - Cover Assy	EA
10D2241	Side Plate	EA
10D2353-1	Bracket Assy - Bellcrank	EA
10D2353-2	Bracket Assy	EA
10D2353-4	Lug	EA
10D2353-5	Side Plate R/H	EA
10D2354-4	Spacer	EA
10D2354-5	Arm	EA
10D2437	Bracket	EA
10D2445	Toe Plate	EA
10D2446-1	Bracket	EA
10D2446-2	Bracket	EA
10D2498-1	Stop	EA
10D2665-1	Gusset Lt.	EA
10D2665-2	Gusset Rt.	EA
10D2673-4	10D2673-4	EA
10D2676	Channel-Tunnel	EA
10D2682-3	Axle, Ski	EA
10D2682-4	Axle, Ski	EA
10D2684-1	Arm Lt.	EA
10D2684-1B	Blank, Arm Lt.	EA
10D2684-2	Arm Rt..	EA
10D2684-2B	Blank, Arm Rt.	EA
10D2684-5	Tube	EA
10D2684-6	Tube	EA
10D2687	Cap, Tunnel	EA
10D2948	End, Cylinder	EA
10D2950	Piston	EA
10D2971	Cover	EA
10D2974-1	Assy-cylinder	EA
10D2993	Brace	EA
10D3124	Bracket	EA
10D3125	Bracket	EA
10D3218-1	Clamp	EA
10D3218-2	Clamp	EA
10D3220	Strap Assy	EA
10D3355-9	Key	EA
10D3358-1	Cover	EA
10D3358-4	Cover	EA
10D3358-6	Cover	EA
10D3363-3	Casting	EA



Part Number	Part Description	Unit of Measure
10D3370-1	Decal, Wipline Ski - Left	EA
10D3370-2	Decal, Wipline Ski - Right	EA
10D3377-1	Fairing; Fwd. Lt.	EA
10D3377-2	Fairing; Fwd. Rt.	EA
10D3377-3	Fairing for C2200 Ski	EA
10D3377-6	Fairing for C2200 Ski	EA
10D3378-1	Fairing Assembly, 3200 Lt	EA
10D3378-2	Fairing Assembly, 3200 Rt	EA
10D3378-3	Fairing, 3200 Ski	EA
10D3378-4	Fairing Strip, Rubber 3200	EA
10D3378-6	Fairing, 3200 Ski	EA
10D3408-3	Casting	EA
10D3428	Reinforcement	EA
10D3429	Plate	EA
10D3440-1	Saddle	EA
10D3440-3	Plate	EA
10D3440-4	Plate	EA
10D3489	Pedestal Assy	EA
10D3495	Pedestal	EA
10D3495-2	Lug	EA
10D3540-7	Tool Steel Key	EA
10D3578-1	Arm, Lt. 3600 ski	EA
10D3578-1B	Blank, Arm 3600 Ski Lt.	EA
10D3578-2	Arm RH 3600 Ski	EA
10D3578-2B	Blank, Arm 3600 Ski RH	EA
10D3578-8	Arm L.H., C3000A Only	EA
10D3578-9	Arm R.H., C3000A Only	EA
10D3592-1	Gusset, left	EA
10D3592-2	Gusset, right	EA
10D3593	Cover. Channel	EA
10D3593-3	Cover Plate Buy 10D3593 complete	EA
10D3593-4	Cover - Curved Buy 10D3593 complete	EA
10D3593-5	Cover - Side Plate Buy 10D3593-5 Complete	EA
10D3596-3	Fairing, Fwd C3600 Ski, Left	EA
10D3596-4	Fairing, Fwd C3600 Ski, Right	EA
10D3596-5	Rubber Strip, Fairing C3600	EA
10D3598-8	Key	EA
10D3606	Cylinder, hydraulic	EA
10D3613	Stop Casting	EA
10D3614	Stop Casting	EA
10D3617-4	Black Neoprene Rubber Fairing Strip	EA
10D3621	Cap	EA
10D3626	Rod	EA
10D3644-4	Tube - Short	EA
10D3644-5	Flange	EA
10D3644-9	Tube	EA
10D3647-43	Binder Strip	EA
10D3784	Cap Cylinder	EA
10D3786	Journal - Cylinder	EA
10D3809-3	Fairing, Fwd Lt (3000A)	EA
10D3809-4	Rubber Strip, Fairing (3000A)	EA
10D3809-6	Fairing, Fwd Rt (3000A)	EA

Part Number	Part Description	Unit of Measure
10D3828	Lug install kit PA-18, Weld on, Cub Crafter, 3" extended, 1 1/4 " Axles. (8.00 x 6 and 8.50 x 6 tire only)	EA
10D970-1	Lug	EA
10D970-3	Saddle	EA
10F3775	Cylinder Assy	EA
10G1024-5	Bottom, A1500A ski	EA
10G1040	Brace	EA
10G1082-26	Barrel	EA
10G1082-27	Barrel	EA
10G1381-7	Spacer	EA
10G1430-42	Spacer	EA
10G1978-1	AWT 2500A Tail Ski	EA
10G2051-1	Beam	EA
10G2051-2	Beam	EA
10G2355-10	Arm	EA
10G2355-11	Arm	EA
10G2355-12	Arm	EA
10G2355-3	Arm	EA
10G2355-4	Cap	EA
10G2355-5	Cap	EA
10G2355-9	Arm	EA
10G2421-6	Runner	EA
10G2440	Gusset	EA
10G2592-2	Bushing	EA
10G2592-3	Pad	EA
10G2640-1	Bottom, Ski C3000 L.H.	EA
10G2640-2	Bottom, Ski C3000 R.H.	EA
10G2642-1	Channel/Tunnel (3200 Ski)	EA
10G2680-1	Bottom, L.H. (C2200 Ski)	EA
10G2680-2	Bottom, R.H. (C2200 Ski)	EA
10G3352-26	Plate	EA
10G3360-12	Washer	EA
10G3360-6	Spacer	EA
10G3360-7	Angle	EA
10G3360-8	Mount - Angle	EA
10G3488	Assembly, Tail Ski, Bottom, CT3000	EA
10G3544-3	Plate	EA
10G3544-6	Lever	EA
10G3559-4	Gusset	EA
10G3566-1	Washer	EA
10G3566-3	Washer	EA
10G3579-1	Channel-(C3600 Series)	EA
10G3580	Liner	EA
10G3620-34	Strip, Wear	EA
10G3620-35	Runner, Outboard 3600	EA
10G3620-5	LDR Bottom	EA
10G3620-92	Spacer, Aft Bungee	EA
10G3620-98	Spacer	EA
10G3627-1	Bottom, Ski left (C3600H)	EA
10G3627-2	Bottom, Ski right (C3600H)	EA
10G3647-41	Binder, Short (3200)	EA
10G3647-43	Binder Strip, Short C3200	EA

Part Number	Part Description	Unit of Measure
10G3647-47	LDR Bottom, C3200 Skis	EA
10G3649-1	Bottom, Ski left (C3200)	EA
10G3649-2	Bottom, Ski right (C3200)	EA
10G3671-13	Binder Strip, 3600 Short	EA
10G3671-9	Binder, Long (3600)	EA
10G3795	Reinforcement	EA
10G902	Saddle	EA
10R1027	Channel	EA
10R1925	Tunnel, NA1200 nose ski	EA
10R2650-069	Ski Bottom; Nylon	EA
10R2650-130	Spacer	EA
10R2650-131	Spacer For Brace	EA
10R2650-59	Rubber Tunnel Insert	EA
10R2650-67	Bottom, LDR 3000 Skis	EA
10R3508-26	End Cap	EA
10R3810-34	Bottom, LDR 3000A Skis	EA
10RX1/2FHA(8 2)	Screw	EA
10RX3/4FHA(8 2)	Screw	EA
1-10374	Key, Metal Bar	EA
11A103	Assy, Cup & Sleeve	EA
11A104	Bushing	EA
11A1051	Lug	EA
11A106	Spacer	EA
11A1065	Pull-off, forward cable AWB2500a skis on Cessna 170	EA
11A107	Spacer/Washer	EA
11A1076-3	V-Ends	EA
11A1079	Washer-Spacer	EA
11A108	Washer-Spacer	EA
11A1081	Spacer	EA
11A1089	Spacer	EA
11A109	Washer-Spacer	EA
11A1092	Handle	EA
11A1096	Barrel	EA
11A110	Axle Adapter	EA
11A1109-1	Bracket	EA
11A1109-2	Lug	EA
11A111	Spacer/Washer	EA
11A1119-1	Fitting - Bent	EA
11A1119-2	Fitting - Flat	EA
11A1122	Rigging Kit	EA
11A1123	Bracket	EA
11A1124	Cable Assy	EA
11A1127	Washer	EA
11A1132	Lug	EA
11A1134	Lug	EA
11A1140	Bungee	EA
11A1157	Dipstick	EA
11A1161	Cable Assy	EA
11A117	Clamp	EA
11A1175	Cable	EA

Part Number	Part Description	Unit of Measure
11A1185	Bracket	EA
11A1187	Bracket	EA
11A1188	Bolt	EA
11A1190	Lug	EA
11A1193	Washer-Spacer	EA
11A1210	Guide	EA
11A1212	Bolt	EA
11A1230	Oil Cooler Strut	EA
11A1248	Cover Gasket	EA
11A1249	Cover - Pull Off	EA
11A1251	Bracket	EA
11A1254	Lug	EA
11A1267	Clamp	EA
11A1273	Axle	EA
11A1274	Washer	EA
11A1275	Spacer	EA
11A1277	Lug - Long	EA
11A1281	Sleeve	EA
11A1295	Bracket	EA
11A131	Spacer	EA
11A1311	Spacer	EA
11A1312	Bracket	EA
11A134	Washer-Spacer	EA
11A1342	Fitting, Fwd.	EA
11A1344	Fitting	EA
11A1345	Bushing	EA
11A1346	Spacer	EA
11A1349-1	Spacer/Washer	EA
11A1351	Bracket	EA
11A1352-1	Fitting	EA
11A1352-3	Washer	EA
11A1360	Bracket, fwd. cable attach (C2200)	EA
11A1364-1	Washer-Spacer	EA
11A1364-2	Washer-Spacer	EA
11A1367	Bracket	EA
11A137	Spacer/Washer	EA
11A1377	Bolt, Modified	EA
11A138	Spacer/Washer	EA
11A1380-1	Bracket, Left Hand	EA
11A1380-2	Bracket, Right Hand	EA
11A1386	Reinforcement	EA
11A1388	Clamp	EA
11A140	Link	EA
11A1402	Lug	EA
11A1406	Lug	EA
11A141	Fitting	EA
11A1415	Bracket/Band	EA
11A1416	Bracket, Fwd Rigging & Limit Cables	EA
11A1425-1	Bracket L.H.,	EA
11A1425-2	Bracket , R.H.	EA
11A1429-2	Shackle	EA
11A143	Bushing	EA

Part Number	Part Description	Unit of Measure
11A1432	Handle	EA
11A1439	Cable Assy	EA
11A1471	Fitting	EA
11A1478-1	Cable Assy	EA
11A1478-2	Cable Assy	EA
11A1481-2	Modified Bracket	EA
11A148-2	Washer	EA
11A1492	Axle Tube	EA
11A1493	Spacer Assy	EA
11A1493A	Tube	EA
11A1493B	Washer	EA
11A151	Washer-Spacer	EA
11A1520	Bracket	EA
11A1527	Bracket	EA
11A1531	Cover	EA
11A1533	Clamp - Hose	EA
11A1542	Bracket	EA
11A1544	Placard	EA
11A1549	Fitting	EA
11A1551-1	Flange Spacer	EA
11A1553	Bolt - Special	EA
11A1559	Axle (Modified Bolt)	EA
11A1559-1	Bolt - Old Style	EA
11A1567	Nut, stub axle	EA
11A1568	Spacer/Washer	EA
11A1570	Plate	EA
11A1571	Plate	EA
11A1580	Washer-Skis	EA
11A1584	Spool	EA
11A1585	Spool	EA
11A1588	Cable Assy	EA
11A159	Bracket - Attach	EA
11A1590	Spacer	EA
11A1591-2	Fitting Adaptor	EA
11A1604	Clamp	EA
11A1618	Washer-Flange	EA
11A172	Axle Nut	EA
11A173	Spacer/Washer	EA
11A176-3	Tube	EA
11A180	Kit	EA
11A182	Kit-Bracket	EA
11A186	Kit-Axle	EA
11A190	Washer	EA
11A217	Washer	EA
11A218-1	Spacer	EA
11A218-3	Spacer	EA
11A242	Bushing Kit	EA
11A261	Kit	EA
11A266	Washer	EA
11A274	Washer-Spacer	EA
11A276	Cessna Kit	EA
11A287	Spacer	EA

Part Number	Part Description	Unit of Measure
11A288	Washer	EA
11A292	Washer	EA
11A310	Flange	EA
11A330	Bracket	EA
11A338	Spring	EA
11A367	Washer	EA
11A381	Bush - Tail Ski Kit	EA
11A382	Bolt	EA
11A407	Bushing (Steel)	EA
11A419	Lug	EA
11A441-1	Rod	EA
11A470	Bracket	EA
11A476	Bracket	EA
11A511	Barrel	EA
11A512	Plate End	EA
11A514	Tube	EA
11A516	Shaft	EA
11A518	Stop Plate	EA
11A519	Plate Spring End	EA
11A644-1	Rigger Barrel	EA
11A645-1	Spacer	EA
11A646	Barrel End	EA
11A647	Lug	EA
11A648	Piston Assy	EA
11A650	Washer	EA
11A673	Gusset	EA
11A674	Socket	EA
11A716	Lug	EA
11A732	Tab	EA
11A733	Plate	EA
11A803	Ring	EA
11A805-3	Bushing	EA
11A806	U-Bolt	EA
11A807	U-Clamp	EA
11A809	Spacer	EA
11A813	Bracket	EA
11A839	Bracket	EA
11A840	Bracket	EA
11A841	Lug	EA
11A846	Spacer/Washer	EA
11A847	Bracket Assy	EA
11A848	Triangle	EA
11A849-2	Limit Cable Assy	EA
11A854	Fitting Assy	EA
11A854-2	Ring	EA
11A857	Washer	EA
11A860	Bolt	EA
11A865	Spring	EA
11A868	Bracket	EA
11A871	Spacer	EA
11A872	Gusset	EA
11A873	Gusset	EA

Part Number	Part Description	Unit of Measure
11A890-1	Spacer, bushing (AWB2500)	EA
11A890-2	Spacer, bushing (AWB2500)	EA
11A912	Spacer	EA
11A914	Bushing (Steel)	EA
11A924	Bumper Bracket	EA
11A927	Bumper Assy	EA
11A942	Spacer	EA
11A943	Tube	EA
11B1052-3	Plate	EA
11B1052-4	Lug	EA
11B1052-5	Plate	EA
11B1056-1	Bracket	EA
11B1056-2	Bracket	EA
11B1082-16	Bushing	EA
11B1083	Cable Attach Bracket	EA
11B1087	Tube Assy	EA
11B1087-1	Tube - Inner	EA
11B1087-2	Tube - Outer	EA
11B1087-3	Washer	EA
11B1088	Rod Assy	EA
11B1088-1	Rod - Rigger	EA
11B1088-2	Collar	EA
11B1089	Collar	EA
11B1090-2	Spring	EA
11B1094	Fitting, cable attach AWB2500 skis on Cessna 170	EA
11B1149-1	Base - Reservoir	EA
11B1149-2	Base - Reservoir	EA
11B1155	Plate	EA
11B1164	Cable Assy	EA
11B1165	Bracket	EA
11B1165-2	Lug	EA
11B1166-1	Arm, rigger left (AWB2500)	EA
11B1166-2	Arm, rigger right (AWB2500)	EA
11B1168-1	Band Assy	EA
11B1169	Bracket	EA
11B1179-1	Pulley	EA
11B1179-2	11B1179-2	EA
11B1181	Lug	EA
11B1182	Bracket Assy	EA
11B1182-1	Bracket	EA
11B1183	Track	EA
11B1195	Cable Assy	EA
11B1209	Pipe	EA
11B1229	Spring	EA
11B1244	Cable	EA
11B1250	Cable	EA
11B1265	Spring	EA
11B127	Cable Assy	EA
11B1272	Plate	EA
11B1278	Arm	EA
11B1280	Bracket	EA
11B1282-1	Bushing	EA

Part Number	Part Description	Unit of Measure
11B1282-2	Washer	EA
11B1283	Cable Assy	EA
11B1284	Cable Assy	EA
11B1285-2	Cable Assy	EA
11B1294	Plate	EA
11B1341	Arm	EA
11B1347-6	Plate	EA
11B1350-1	Bracket Lt.	EA
11B1350-2	Bracket Rt.	EA
11B1350-3	Bracket	EA
11B1350-4	Bracket	EA
11B1354-1	Limit Cable Assy-Fwd	EA
11B1354-11	Cable Assembly, Maule	EA
11B1354-2	Cable Assembly, Fwd Limit 172	EA
11B1361	Strut(Stock PA-18 Gear Only)	EA
11B1361-3	Tube	EA
11B1361-4	Bushing	EA
11B1361-5	Tab	EA
11B1361-6	Lug	EA
11B1361-7	Gusset	EA
11B1365-1	Strap	EA
11B1365-2	Strap	EA
11B1365-3	Arm	EA
11B1365-4	Arm	EA
11B1368	Plate - Pump Mounting	EA
11B1369-1	Bracket, L.H.	EA
11B1369-2	Bracket, R. H.	EA
11B1376	Lug - Long	EA
11B1385	Bracket	EA
11B1410-1	Hose Assembly C3200	EA
11B1410-2	Hose Assembly C-3200	EA
11B1410-3	Hose Assembly C3600	EA
11B1410-4	Hose Assembly C3600	EA
11B1420-1	Hose Assembly C-2200	EA
11B1420-2	Hose Assembly C-2200	EA
11B1420-3	Hose Assembly C-2200	EA
11B1420-4	Hose Assembly C-2200	EA
11B1448	Cable Assy	EA
11B1449	Cable Assy	EA
11B1451-1	Handle, Pump	EA
11B1451-1A	Handle	EA
11B1451-1B	Handle	EA
11B1451-2	Handle	EA
11B1451-2A	Handle	EA
11B1452-1	Bracket	EA
11B1452-2	Bracket	EA
11B1460	Bracket	EA
11B1480-1	Cable, Limit	EA
11B1480-2	Cable, Limit	EA
11B1486	Cable Assy - Fwd	EA
11B1487-1	Cable Assy	EA
11B1490-1	Cable Assy	EA



Part Number	Part Description	Unit of Measure
11B1490-2	Cable Assy	EA
11B1491-2	Washer-Spacer	EA
11B1495-3	Pin	EA
11B1498	Cable Assy	EA
11B1507	Safety Cable Assy	EA
11B1519-1	Bracket L.H.	EA
11B1519-2	Bracket R.H.	EA
11B1537	Bracket	EA
11B1551-2	Fitting	EA
11B1551-3	Bushing	EA
11B1552-1	11B1552-1	EA
11B1555	Limit Cable Fwd.3600 Skis	EA
11B1555-1	Assembly, Limit Cable	EA
11B1557-1	Bracket	EA
11B1557-2	Bracket	EA
11B1569-1	Fitting, Left	EA
11B1569-2	Fitting, Right	EA
11B1578	Spring	EA
11B1596-2	Band	EA
11B160	Bracket	EA
11B1609	Limit Cable	EA
11B1610	Limit Cable	EA
11B1637	Spacer - Axle	EA
11B1638	Band	EA
11B1641	Spacer - Axle	EA
11B1642	Spacer - Sleeve	EA
11B1643	Bracket	EA
11B1645	Bar	EA
11B1646	Spacer	EA
11B1647	Washer	EA
11B1648	Bushing	EA
11B1651	Rigger Bracket	EA
11B1652	Clip	EA
11B1665	Stud Axle	EA
11B1674	J Bolt	EA
11B1682	Rigging Bracket	EA
11B1688	Nameplate	EA
11B1695	Spacer	EA
11B557-1	Arm, Rigger, Attach, Lt., Cessna 170/170A	EA
11B557-2	Arm, Rigger, Attach, RH, Cessna 170/170A	EA
11B731	Bracket	EA
11B744-1	Band	EA
11B811-3	T.S. Kit	EA
11B812-1	Tail - Ski Rigging Bracket	EA
11B812-3	Bracket	EA
11B856-1	Bracket	EA
11B859	Limit Cable Assy	EA
11B870	Arm	EA
11B876-1	Arm	EA
11B876-2	Arm	EA
11B877-1	Arm	EA
11B877-2	Arm	EA

Part Number	Part Description	Unit of Measure
11B893-1	Arm	EA
11B915	Rigging Bracket	EA
11B921	Cyl Bracket	EA
11B981	Plate	EA
11D1053	Cable Bracket	EA
11D1054	Cable	EA
11D1059-13	Bushing	EA
11D1063-2	Cable	EA
11D1069-13	Frame Assy	EA
11D1069-14	Bracket Assy	EA
11D1069-2	Cross Tube	EA
11D1069-3	Outer Tube	EA
11D1069-4	Stop	EA
11D1069-5	Inner Tube	EA
11D1069-6	Bar	EA
11D1069-7	Lug	EA
11D1069-8	Washer	EA
11D1076-10	Frame Assy	EA
11D1076-11	Thimble	EA
11D1076-4	Tube	EA
11D1076-5	Lug	EA
11D1076-6	Lug	EA
11D1076-7	Washer	EA
11D1085-1	Cable Assy	EA
11D1110	Strut	EA
11D1177-1	Bracket	EA
11D1177-2	Plate	EA
11D1177-3	Plate	EA
11D1177-4	Curved Plate	EA
11D1178-2	Lug	EA
11D1178-3	Gusset	EA
11D1178-5	Plate	EA
11D1178-6	Cap	EA
11D1178-7	Cover Plate	EA
11D1178-8	Washer	EA
11D1180	Bracket Assy	EA
11D1231	V-Bracket	EA
11D1256-4	Bracket	EA
11D1256-5	Bracket	EA
11D1294	Bracket	EA
11D1303	Bracket Assy	EA
11D1331	Cable	EA
11D1335-11	Bushing	EA
11D1335-2	Cable Assy	EA
11D1359-1	Bracket, Left	EA
11D1359-2	Bracket, Right	EA
11D1359-3	Plate	EA
11D1359-4	Strap	EA
11D1359-5	Strap	EA
11D1359-6	Strap	EA
11D1366-13	Lug, Rigger, Shock Cord	EA
11D1366-2	Rigger Assembly, Fwd.	EA

Part Number	Part Description	Unit of Measure
11D1366-3	Rigger Assembly, 3" Extended Gear	EA
11D1366-4	Lug	EA
11D1371-2	Cable Assy	EA
11D1375-1	Cable Assy. Aft. Pull Off (C2200)	EA
11D1375-3	Ring	EA
11D1389-13	Reservoir - Weld	EA
11D1389-7	Reservoir - Elbow - Mod	EA
11D1389-8	Reservoir Union - Mod	EA
11D142	Cable	EA
11D1434-3	Bracket	EA
11D1434-4	Bracket	EA
11D1434-6	Spool	EA
11D1434-7	Bushing	EA
11D1434-8	Side Plate	EA
11D1434-9	Fork Plate - One Hole	EA
11D1445	Bushing	EA
11D1488	Clamp	EA
11D1488-1	Band	EA
11D1488-2	Plate	EA
11D1491-3	Washer	EA
11D1524	Bracket	EA
11D1534-1	Bracket	EA
11D1534-2	Bracket	EA
11D1534-5	Band	EA
11D1534-6	Strip	EA
11D1534-7	Support	EA
11D1534-8	Band	EA
11D1535-1	Bracket	EA
11D1535-4	Band	EA
11D1535-5	Band	EA
11D1535-6	Strip	EA
11D1556	Bungee Assembly, Aft	EA
11D1556-16	Cable, Limit Aft.	EA
11D1556-7	Bushing	EA
11D159	Bracket Assy	EA
11D1595	Welded Flange	EA
11D1601-1	Bracket	EA
11D1635-1	Tail - Ski Rigging Kit	EA
11D1639-1	Bracket	EA
11D1639-2	Bracket	EA
11D1644	Plate	EA
11D1649	Rigger Assy	EA
11D1657	Rigger Assy	EA
11D1658-1	Fork Weldment	EA
11D1659	Rigging Bracket	EA
11D1660-1	Rigging Bracket	EA
11D1660-2	Rigging Bracket	EA
11D1660-3	Plate	EA
11D1660-4	Strap	EA
11D1660-5	Gusset	EA
11D1660-6	Gusset	EA
11D1660-7	Plate	EA

Part Number	Part Description	Unit of Measure
11D1660-8	Gusset	EA
11D1660-9	Gusset	EA
11D1668	Aft Safety Cable	EA
11D1672-1	Hyd Clamp	EA
11D1672-2	Hyd Clamp	EA
11D1672-3	Bracket Clamp	EA
11D1672-4	Bracket Clamp	EA
11D1672-5	Clamp	EA
11D1679-2	Assembly, rigger (MAULE double bungee)	EA
11D168	Saddle	EA
11D1684	Shock Cord Assy	EA
11D1696	Bracket	EA
11D332	Mechanical Rigger	EA
11D455-1	Bracket	EA
11D455-2	Bracket	EA
11D742-1	Bracket	EA
11D743	Bracket	EA
11D744-2	Band	EA
11D858-3	Clamp L/H	EA
11D858-4	Clamp R/H	EA
11D952	Bracket	EA
11G1082-10	Tube	EA
11G1082-11	Tube	EA
11G1082-15	Spacer	EA
11G1082-16	Bushing	EA
11G1082-17	Gusset	EA
11G1082-8	Rod End	EA
11G1235	Flange	EA
11G1339-1	Bungee Assembly	EA
11G1339-16	Cable Assembly	EA
11G1339-3	Bar, Rigger	EA
11G1339-4	Lug	EA
11G1339-5	Bushing	EA
11G1339-6	Washer, Aft. Limit Cable	EA
11G1347-1	Wall	EA
11G1347-5	Wall - Bottom & Sides	EA
11G1354-11	Limit Cable - Fwd	EA
11G1357-1	Bracket L.H.	EA
11G1357-10	Channel R/H	EA
11G1357-11	Bracket	EA
11G1357-12	Bracket	EA
11G1357-2	Bracket R.H.	EA
11G1357-3	Channel	EA
11G1357-4	Lug	EA
11G1357-5	Lug	EA
11G1357-6	Gusset	EA
11G1357-8	Lug	EA
11G1370-22	Bushing	EA
11G1379-3	Bracket	EA
11G1381-20	Bracket	EA
11G1381-26	Spacer	EA
11G1381-27	Spacer	EA

Part Number	Part Description	Unit of Measure
11G1381-7	Plate	EA
11G1389-4	Reservoir - Shell	EA
11G1417-1	Bracket	EA
11G1417-2	Bracket	EA
11G1426-10	Plate	EA
11G1482-3	Bar	EA
11G1482-4	Lug	EA
11G1482-6	Bushing	EA
11G1482-7	Washer	EA
11G1526-5	Plate	EA
11G1526-6	Arm	EA
11G1554-1	Assy, Rigger	EA
11G1554-21-24	Cable Rigger. Fwd. 24in	EA
11G1554-21-9 1/4	Cable, Forward Rigger - 9 1/4	EA
11G1554-7	Lug	EA
11G1555-2	Cable	EA
11G1683	Rigging Cable Assy	EA
11G1683-7	Bar	EA
11G348-1	Bracket	EA
11G348-2	Band	EA
11G348-3	Washer	EA
11G3822-1	Bracket Assembly,Ski Attach	EA
11G3822-2	Bracket Assembly, Ski Attach	EA
11G941	Assy Rigger	EA
11R1670-5	Spacer	EA
13A12649-001	Shim, Rudder Stop	EA
186083	Bracket	EA
18-7691	Pin	EA
187719-4	Tube Assembly, 3/8" Shaft, 1-3/8" Sprocket	EA
18-7735-1	Sprocket, 1-3/8"	EA
190296-4S	Hose End Fitting, 45 Deg, 3/8", 1/2", Aluminum Chromate	EA
23056-1-4	Hose Tag	EA
3025A	Snap, Finished, As Is	EA
37569-03	Cable Check Fitting(Husky Only)	EA
3F1253	Holder, Light Bulb, 1/4"	EA
500C22MIL158	Bungee Cord 1/2" for Skis	FT
5881V	Bearing, Nice, 1/2" DIA, Flylite #F4218-5	EA
84-39-927-1	End Cap, Unfinished	EA
9010CW	Aero Ring, Shock Cord, 5/8" Thick, 33-1/2" Loop	EA
9044CW	Aero Ring, Shock Cord, 1/2" Thick, 48" Loop	EA
9060CW	Aero Ring, Shock Cord, 5/8" Thick, 22" Loop	EA
9-1624-31	Spring, Thick, Small, 1" DIA	EA
9-3224-31	Spring, Thick, Large, 2" DIA	EA
9714S-9P	Plug, SOLDER, 97 SERIES	EA
9714S-9S	INSERT + CONTACT ASSY, 97 SERIES, ROHS	EA
9718-6S	Plug, MIL-C-5015 type Connectors	EA
97-3057-10	Connector Accessory, Cable Clamp, Olive Drab Finish, 5/8"	EA
97-3057-6	Connector Accessory, Cable Clamp, Nickel Finish, 3/4"	EA
97-3102A-14S	Connector, Receptacle, 3/4"	EA

Part Number	Part Description	Unit of Measure
97-3102A-18	Connector, Receptacle, 1"	EA
97-3106A-14S	Connector, Plug, Straight, 3/4"	EA
97-3106A-18	Connector, Plug, Straight, 1"	EA
97-3108A-18	Connector, Plug, Angle, 1"	EA
980006	Hose End Fitting, 45 Deg	EA
A1859	Pedestal Tube	EA
A1860	Pedestal Tube	EA
A-1863	Bushing Rubber	EA
A2021	Pedestal Half Shell	EA
A2022	Shell - Flat	EA
A3506	Pedestal Half Shell	EA
A3508-1	Tube	EA
A3509-3	Tube	EA
A3516	Flange Spacer	EA
A81528-1	Cup	EA
AA1512-2	Bushing (C5500 ski)	EA
AA1512-5	Bushing (S1503)	EA
AA1704-15	Bushing	EA
AA1803-10	Bushing	EA
AB-1529	Bushing, Steel	EA
AR1501-2	Bungee tab (2) 1/4" holes	EA
AR1501-4	Bungee tab (1) 1/4" hole, (1) 3/8" hole	EA
AR-3520-1	Fitting, Cable Attach	EA
ARE-6N	Rod End Bearing	EA
AT2001	Skag	EA
AT2003	Channel	EA
AT2005	Saddle Plate	EA
AT2006	Axle Tube	EA
AWB2500A	Spacer	EA
AWB3500	AWB3500	EA
AWN-1200	Bracket	EA
AWN-1200A	Panel	EA
AWSR3114-6	Bracket	EA
AWSR3126	Lug	EA
AWSR3180-1	Shell	EA
AWSR3182	Access Cover	EA
AWSR3190-1	Eyebolt	EA
AWSR3190-2	Eyebolt	EA
AWSR3191	Stub Bolt	EA
AWSR3195	Plate - Airfoil	EA
AWSR3196	Plate, Bracket	EA
AWSR3198-1	Strip Plate	EA
AWSR3198-2	Plate	EA
AWSR3201	Tapered Channel	EA
AWSR3202	Bracket	EA
AWSR3205	Spacer	EA
AWSR3215	Wire Retainer	EA
AWSR3222	Cap	EA
AWSR3233-1	Clevis	EA
AWSR3233-2	End Hyd. Cyl.	EA
AWSR3240	Hydraulic Bracket	EA
AWSR3242	Lug	EA

Part Number	Part Description	Unit of Measure
AWSR3243	Spacer	EA
AWSR3244	Spacer	EA
AWSR3247-1	Cylinder-Pin	EA
AWSR3247-2	Cylinder-Pin	EA
AWSR3248	Bolt	EA
AWSR3249	Pin	EA
AWSR3250	Tab	EA
AWSR3252-1	Bracket	EA
AWSR3252-2	Bracket	EA
AWSR3252-3	Lug	EA
AWSR3252-7	Bracket	EA
AWSR3263	Bracket	EA
B06002-1	Plate Do not buy	EA
B06002-2	Rings Do not buy	EA
B06004	Insert	EA
B06006	Bushing Modified	EA
B06008	Poly Sliding Surface	EA
B06009-1	Beam Assy. - R.H.	EA
B06009-2	Beam Assy. - L.H.	EA
B06011	-Rigger Bracket	EA
B06012	Wear Strip	EA
B06014	Clevis	EA
B06015	Trunion	EA
B06016	Shaft	EA
B06017	Rubber	EA
B06018	Washer	EA
B06019	Washer	EA
B1003	Brace Fork Do not buy	EA
B1004	Deck Sheet Do not buy	EA
B1005	Cap Do not buy	EA
B1006	Rubber Pad Do not buy	EA
B1008	Bolt - Clamp Do not buy	EA
B1009	Clamp Assy. Fork Do not buy	EA
B1013-2	Nameplate Do not buy	EA
B102-1	Tube (axle)	EA
B102-17	Tube Do not buy	EA
B102-5	Tube Yoke Mt. Do not buy	EA
B105-3	Tube Do not buy	EA
B1055	Plug - Button 1 1/4" Do not buy	EA
B106-17	Cable Do not buy	EA
B106-18	Cable Do not buy	EA
B111-1	Lock Ring	EA
B112-1	Clip	EA
B113	Lug	EA
B12030	Support Angle	EA
B12036	Spacer	EA
B12038	Yoke Insert	EA
B12046	Fork Leg	EA
B12071	Spring Pad	EA
B12075-2	Base	EA
B12087	Cyl. Lock Ring	EA
B12088	Scraper Ring	EA

Part Number	Part Description	Unit of Measure
B12093	Cyl. Clamp Angle	EA
B12093-1	Angle	EA
B122	Shim	EA
B13030	Blank	EA
B1716	Plug - Button 3/4"	EA
B1809	Bushing	EA
B2008	Bushing	EA
B2013	Lug	EA
B2025	Cups	EA
B2052	Plate	EA
B2057	Bracket	EA
B2059	Cyl. Mount Assy.	EA
B2060-2	Weld Assy.	EA
B2061	Scuff Plate	EA
B2062	Scuff Plate	EA
B2062-1	Scuff Plate	EA
B2066	Lug	EA
B2067	Shaft Bracket	EA
B2501	Bracket	EA
B2504	Yoke Arm Saddle	EA
B2504-1	Tube	EA
B2509	Axle Heel Roller	EA
B2511	Rod	EA
B2519-1	Cam - Tr. Plate	EA
B2519-2	Cam - Tr. Plate	EA
B2522-1	Cable Assy.	EA
B2522-2	Cable Assy.	EA
B2529-1	Axle Insert	EA
B2529-2	Axle Insert	EA
B2532-2	Bracket	EA
B2537-2	Channel	EA
B2538-2	Block	EA
B2539	Back Strap	EA
B2546	Axle Insert	EA
B2547	Clamp	EA
B2548	Clamp	EA
B2576	Strut	EA
B2576-2	Tube	EA
B2579	Channel	EA
B2582	L Bracket	EA
B2583	Bar	EA
B2587	Spacer	EA
B2588	Plate	EA
B2591	Retainer	EA
B2593	Clip, beam	EA
B3031-1	Data Tag	EA
B3031-1	Data Tag	EA
B3031-2	Tag - Less F.A.A.	EA
B3035	Bearing	EA
B3037	Placard	EA
B3038	B3038	EA
B3041-1	Rigger Assy.	EA



Part Number	Part Description	Unit of Measure
B3042-3	Spacer	EA
B3042-4	B3042-4	EA
B3042-5	B3042-5	EA
B3042-6	B3042-6	EA
B3043	B3043	EA
B3045-5	Rod Assy.	EA
B3045-6	Rod Assy.	EA
B3047-1	Bracket	EA
B3048	Rigger Shackle	EA
B3049	Spool	EA
B3064	Wear strip	EA
B3078	Saddle	EA
B3102-1	Heel Roller Axle	EA
B3102-2	Heel Roller Axle	EA
B3105	Piston	EA
B3106-1	Rod, Piston	EA
B3108	End, cylinder (ROD)	EA
B3109	End, cylinder	EA
B3111-4	Rubber Pad	EA
B3112-1	Cyl. Mount	EA
B3112-2	Cylinder-Mount	EA
B3114	Scuff Plate	EA
B3117-1	Cyl. Mt.	EA
B3117-2	Cyl. Mt.	EA
B3118	Ring, Feed	EA
B3121	Plate	EA
B3123	Cable Bracket	EA
B3134	Dip Stick	EA
B3135-10	End Reservoir	EA
B3135-11	Box Reservoir	EA
B3135-12	Boss 1/2	EA
B3135-13	Boss 3/8	EA
B3135-9	End 3/8" Boss	EA
B3139-3	Tube	EA
B3152	Cover	EA
B3153	Handle, Selector Valve	EA
B3155	Bracket	EA
B3162	Reinforcement	EA
B3164-2	Axle, Trail Wheel Lt. (FLI-LITE 3000)	EA
B3165-1	Arm	EA
B3165-2	Arm	EA
B3166	Body	EA
B3167	Bushing	EA
B3172	Bracket	EA
B3189	Base	EA
B3192	Bolt	EA
B3195	Axle Trail Wheel - production	EA
B3198-1	Brace	EA
B3199	Plate	EA
B3202	U Bracket	EA
B3203	Lug	EA
B3205	Arm	EA

Part Number	Part Description	Unit of Measure
B3301	Axle (FLILITE on Cessna )	EA
B3310-3	Line Lug	EA
B3310-4	Axle Lug	EA
B3319-3	Cable Fitting	EA
B3322-1	Axle, extension	EA
B3323-2	Bolt Axle	EA
B3327-10	Cable Assy.	EA
B3327-11	Cable	EA
B3327-12	Cable Assy.	EA
B3327-9	Cable Assy.	EA
B3333	Channel Plum Mounting	EA
B3402	Insert, axle	EA
B3403	Insert Yoke	EA
B3405	Bracket	EA
B3406	Shaft	EA
B3407-1	Axle, right (PA18 on FLILITE 3000)	EA
B3407-2	Axle, left (PA18 on FLILITE 3000)	EA
B3408	Nut - Axle	EA
B3409	Axle Clamp	EA
B3415	Plate	EA
B3418	Lug	EA
B3419	Bracket, cable attach	EA
B3421-15	Cable	EA
B3421-18	Cable Assy.	EA
B3421-20	Cable Assy.	EA
B3421-3	Cable Assy.	EA
B3421-4	Assembly, cable aft rigging (Fililite 3000 /185)	EA
B3421-9	Cable	EA
B3505	Plate	EA
B3509	Cable Assy.	EA
B3511	Cable	EA
B3512-10	Cable Assy.	EA
B3512-11	Cable Assy.	EA
B3512-12	Cable Assy.	EA
B3512-3	Cable Assy.	EA
B3603-1	Bracket Assy.	EA
B3603-2	Bracket Assy.	EA
B3604-1	Bracket Assy.	EA
B3604-2	Bracket Assy.	EA
B3605	Bracket	EA
B3614	Bent Plate	EA
B4012-8	Bushing	EA
B4013	Reinforcement	EA
B4020-1	B4020-1	EA
B4020-2	B4020-2	EA
B4023-2	Cable Assembly	EA
B4057	Side Plate	EA
B4059-3	Pivot Tube	EA
B4062-1	Yoke Tube	EA
B4062-2	Yoke Tube	EA
B4063	Saddle Assy.	EA
B4064	Saddle	EA

Part Number	Part Description	Unit of Measure
B4065	Scuff Plate	EA
B4068	Bracket, Cylinder Mount (Transfer Plate)	EA
B4073	Cap, cylinder blind end (for F4069)	EA
B4075	Piston	EA
B4078-1	Cylinder Mount	EA
B4080	Strip, wear	EA
B4084	Strap	EA
B4085	Spacer	EA
B4092	Bracket, (FLILITE 4000)	EA
B4092-1	Bracket	EA
B4104	Placard	EA
B4209	Bent Plate	EA
B4210-1	Bracket	EA
B4210-2	Bracket	EA
B4211	Bracket	EA
B4214	Decal	EA
B4215	Decal	EA
B4216	Bushing	EA
B4217	Decal	EA
B4301	Bracket	EA
B4302-1	Bracket RH	EA
B4302-2	Bracket Left	EA
B4304	Doubler	EA
B4311	Handle	EA
B4313-7	Rigger Assy.	EA
B4313-8	Cable	EA
B4314-5	Rigger Assy. - Rear	EA
B4324	Aft Rigging Bracket Base	EA
B4325-1	Tang R/H	EA
B4325-2	Tang L/H	EA
B4326-1	Aft Bracket Assy.	EA
B4326-2	Aft Bracket Assy.	EA
B4406	Spacer	EA
B4407	Spacer	EA
B4410	Tube	EA
B4411	Bolt	EA
B4412	Bracket	EA
B4420	Dip Stick	EA
B4421-3	Bracket	EA
B4421-4	Lug	EA
B4425-1	Cable	EA
B4429-1	Handle - Hand Pump	EA
B4429-3	Handle	EA
B4430	Bent Plate	EA
B4431	Channel	EA
B4438	Spacer	EA
B467	Screw	EA
B6013-1	Fork	EA
B6013-2	Fork	EA
B6015	Crank	EA
B6017	Cross Tube Assy.	EA
B6017-1	Tube - Outer	EA

Part Number	Part Description	Unit of Measure
B6021	Rigging Bracket	EA
B6021-1	Plate	EA
B6025	Rigging Bracket - Fwd.	EA
B6026	Cable Assy.	EA
B6033-1	Spring RH	EA
B6033-2	Spring LH	EA
B6036	Cable Assy.	EA
B6038	Cable Assy.	EA
B6039-1	Shackle	EA
B6039-2	Shackle	EA
B6045	Cable Bracket	EA
B6048	Wear Strip - Short	EA
B6049	Cable Assy.	EA
B6050	Cable Assy.	EA
B6200-1	Arm - Yoke Pivot	EA
B6200-2	Arm - Yoke Pivot	EA
B6202	Band	EA
B6203-1	Gusset	EA
B6203-2	Gusset	EA
B6205-1	Heel Roller Saddle Assy.	EA
B6205-2	Heel Roller Saddle Assy.	EA
B6206	Saddle Plate	EA
B6207-1	Plate - Short	EA
B6207-2	Tube	EA
B6207-3	Plate - Long	EA
B6211	Yoke Arm Stop Assy.	EA
B6211-1	Bracket	EA
B6211-2	Rubber Block	EA
B6213-1	Spacer (FLILITE 6000)	EA
B6213-2	Spacer (FLILITE 6000)	EA
B6216	Bushing (FLILITE 6000)	EA
B6507-3	Bracket	EA
B6507-4	Plate	EA
B6518	Wear Strips	EA
B6520	B6520	EA
B6521-1	Hold Down Cam	EA
B6521-2	Hold Down Cam	EA
B6530	Clamp	EA
B6545	Jam Ring + Gage	EA
B6550	Bushing	EA
B6570	Fork Leg	EA
B6578	Stud, Long	EA
B6604	Fwd. Rigging Bracket Assy.	EA
B6605-1	Reinforcement	EA
B6605-2	Bracket	EA
B6634	Side Plate	EA
B7140	Washers	EA
B810-6	Bushing	EA
B98OH	Bearing, Roller Pin, 1/2" DIA	EA
C13013	Yoke Plate Do not buy	EA
C13021-1	Aft. Rigging Bracket Do not buy	EA
C13021-2	Aft. Rigging Bracket Do not buy	EA

Part Number	Part Description	Unit of Measure
C1805	Bracket Do not buy	EA
C1806	Bracket Do not buy	EA
C1807	Bracket Do not buy	EA
C1808	Cable Assy	EA
C2508-1	Assembly, heel roller axle (FLILITE NOSE SKI)	EA
C2508-2	Heel Roller Axle	EA
C2536	Stagger Plate	EA
C2543-1	Bracket, rigging L.H. (aft)	EA
C2543-2	Bracket, rigging R.H. (aft)	EA
C2544	Aft. Right Rigging Hand Bracket	EA
C2549-1	Bracket Support	EA
C2549-2	Bracket	EA
C2578	Stabilizer	EA
C2589	Support Rigging Fwd.	EA
C2590	Support	EA
C3125-1	Cable Assy.	EA
C3125-4	Cable Assy.	EA
C3125-6	Cable Assy.	EA
C3125-8	Cable Assy.	EA
CC2003	Oilite Tube	YD
CLS100-1	Spring	EA
CLS100-2	Ring, Loop	EA
CLS100-4	Ring, Lock (Hog Ring)	EA
D1803-2	Lug Do not buy	EA
D1803-3	Pipe Do not buy	EA
D1803-4	Bracket Do not buy	EA
D1804	Bracket Do not buy	EA
D1804-2	Lug	EA
D1804-3	Lug Do not buy	EA
D1804-4	Pipe Do not buy	EA
D1804-5	Pipe Do not buy	EA
F06001	Bottom	EA
F06010	Rigger Assembly	EA
F1002-1	Beam - Axle	EA
F1002-2	Beam - Axle	EA
F13007-2	Arm	EA
F13007-3	Arm	EA
F13007-5	Gusset	EA
F13007-6	Gusset	EA
F2051-15	Plate	EA
F2071-5	Plate	EA
F2506-6	Plate	EA
F2506-7	Plate	EA
F2513-16	Plate	EA
F2513-17	Spacer	EA
F2521-2	Rigger Assy.	EA
F3030-1	Rigger Assy.	EA
F3040-19	Cable Assy.	EA
F3056-2	Bent Tube	EA
F3056-4	Bent Tube	EA
F3158	Plate	EA
F3187	Hydraulic Line	EA

Part Number	Part Description	Unit of Measure
F3188-1	Plate	EA
F3188-4	Plate	EA
F4020-1	Axle	EA
F4020-2	Axle	EA
F4093-4	Cover, Pump Top	EA
F4093-6	Cover Side	EA
F4093-7	Cover Side	EA
F4093-8	Cover Top	EA
F4218-2	Hub	EA
F4218-3	Hub	EA
F4218-6	Tire, trail wheel FLILITE 4000 series	EA
F4218-80	Tire	EA
F4424-1	Rigger Assy.	EA
F4424-2	Rigger Assy.	EA
F6016	Fork Assy.	EA
F6027	Rigger Cable	EA
F6028	Rigger Assy.	EA
F6049	Cable Assy.	EA
F6100-2	Axle	EA
F6204-5	Bushing	EA
F6507-6	Gusset	EA
F6520-3	Lug	EA
F6597-2	F6597-2	EA
F6597-3	Strap	EA
F6597-4	Bushing - Top	EA
F6597-5	Gusset	EA
F6597-7	Sleeve	EA
F6597-8	Cross Tube	EA
F6597-9	Arm - Bent	EA
F6601-24	Cam Plate	EA
FF1505	Bushing	EA
FF1506-4	Bushing	EA
FF1704-4	Bushing (C5500 ski)	EA
FF838-1	Bushing	EA
HXP-86	Spring, Thick, 2" DIA, Green	EA
I-11470	Lever	EA
I-7642-2	Seal, Black, 5/8" Length	EA
I-7643-4	Seal, Black, 2-3/8" Length	EA
I8014	Gasket, 2-1/2" DIA, Copper	EA
I-9209	Cover Reservoir	EA
JIC-1	Wiper Ring, 5/8" DIA	EA
JIC-5	Wiper Ring, 3/4" DIA	EA
KA211	Axle - Tail Ski	EA
KA267	Axle Assy.	EA
KA320	Axle Assy.	EA
KA431	Bracket Kit	EA
KA44-1	Rigging Kit	EA
KA506	Rigging Kit	EA
LR101-1	Band, Steel	EA
LR101-2	Lug	EA
MRV4-10V-D-6T	Valve, Hydraulic, Manual Rotary	EA

Part Number	Part Description	Unit of Measure
MS27224-4	Back Up Retainer, Fitting, Thickness 0.045-0.052", Width 0.052-0.054", DIA 0.1"	EA
MS27226-4	Fitting, 45 Deg, 1/2" to 3/8"	EA
R4-D8	CHANNEL PAD	EA
SARB2500-10	Lug Bracket	EA
SARB2503	Lug	EA
SARB2504	Pad	EA
SARB2505	Spacer	EA
SB2501	Tube	EA
SB-6	Swivel Bushing, 3/8" DIA	EA
Skicrate	Shipping crate for A/C ski's	EA
SPWRT 434	Bushing, 1" DIA	EA
SPWRT 446	Spacer Nut, 3/4-16 Thread	EA
WST-3014	Bushing, 5/8" DIA	EA
WST-3018	Bracket, 1 Hole at 7/8", 1 Hole at 3/8"	EA
WST-3022	Tube, 5/8" DIA	EA
WST-3023	Bushing, 5/8" DIA	EA
WST-3025	Bracket, 45 Deg, 1 Hole at 3/4", 4 Holes at 1/4"	EA
WST-3027	Spacer, 3/8" DIA	EA
XB1051	Safeline Clamp, 1/8"	EA
XB1054	Safeline Clamp, 1/4"	EA
XM-2B-1100R/WL	Pressure Switch, 1 Black Wire, 1 Blue Wire, 3/8" DIA Connector, WL 220	EA
XM-2B-1250R	Pressure Switch, 1 Black Wire, 1 Blue Wire, 3/8" DIA Connector, WL 243	EA