



Wipaire Non-Production Model Float Parts

Wipaire Parts Sales Team:

1.888.947.2473

WIPLINE FLOATS - SKIS - MODIFICATIONS

Direct: 1.888.947.2473 | Fax: 651.451.1786 | www.wipaire.com
1700 Henry Avenue South - Fleming Field (KSGS) South St. Paul, MN 55075

Part Number	Part Description	Unit of Measure
1 1/2IN BLACK HINGE	Black Plastic Hinge Old 6000 Baggage Covers	FT
1002140	Bolt, Nose Bumper, Attach	EA
31108811	Magnet Holder	EA
3A01000-003	Bulkhead Assy. Stn. #7.5	EA
3A01000-008	Reinfcmt. Assy.-Sm. St.#1 --Use 3A01000-269--	EA
3a01000-009	Unknown	EA
3A01000-010	Reinfcmt. Assy.-Sm. St.#2 --Use 3A01000-269--	EA
3A01000-011	Reinfcmt. Assy.-Sm. St.#3 --Use 3A01000-269--	EA
3A01000-012	Reinfcmt. Assy.-Sm. St.#3 --Use 3A01000-269--	EA
3a01000-013	Unknown	EA
3A01000-014	Reinfcmt. Assy.-Sm. St.#4 R--Use 3A01000-269--	EA
3A01000-019	Reinfcmt. Assy.-Med. St.#3--Use 3A01000-270---	EA
3A01000-020	Reinfcmt. Assy.-Med. St.#3--Use 3A01000-270---	EA
3A01002-002	Strip, Filler Top Stn. #2	EA
3A01002-013	Bulkhead Stn. #11.5 AMPHIB	EA
3A01002-014	Bulkhead Stn. #12.5	EA
3A01002-015	Bulkhead Stn. #15	EA
3A01002-017	Bulkhead Stn. #17	EA
3A01002-019	Stiffener, Top Stn. #19	EA
3A01002-020	Stiffener, Bottom Stn. #19	EA
3A01005-002	Bulkhead Stn. #7.5 Rt.	EA
3A01005-003	Bulkhead Stn. #7.5 Lt.	EA
3A01005-016	Skin, Wheel Well Top	EA
3A01005-018	Skin, Wheel Well Rt.	EA
3A01005-019	Doubler, Carrythru Strap	EA
3A01008-001	Doubler, Step St. Hyd. Fitting	EA
3A01008-003	Plate, Strut Attach Reinforcement	EA
3A01151-001	Stiffener, Side Skin #1	EA
3A01151-002	Stiffener, Side Skin #2	EA
3A01151-003	Stiffener, Side Skin #3	EA
3A01151-004	Stiffener, Side Skin #4	EA
3A01151-005	Stiffener, Side Skin #5	EA
3A01151-006	Stiffener, Side Skin #6	EA
3A01151-007	Stiffener, Side Skin #7	EA
3A01151-008	Stiffener, Top Skin	EA
3A01151-009	Stiffener, Top Skin	EA
3a01151-011	Unknown	EA
3A01151-012	Flange C Station 4	EA
3A01151-013	Flange B Station 4	EA
3A01151-014	Flange D Station 4	EA
3A01151-015	Flange A Station 5.6	EA
3A01151-016	Flange C Station 5.6	EA
3A01151-017	Flange B Station 5.6	EA
3A01151-018	Flange D Station 5.6	EA
3A01151-019	Flange A Station 6.5	EA
3A01151-020	Flange C Station 6.5	EA
3A01151-021	Flange B Station 6.5	EA
3A01151-022	Flange D Station 6.5	EA
3A01151-024	Flange-C-Station 8.5	EA
3A01151-025	Flange-B-Station 8.5	EA
3A01151-026	Flange-D-Station 8.5	EA
3A01151-028	Skin, Btm. Rt.	EA

Part Number	Part Description	Unit of Measure
3A01151-029	Skin, Btm. Lt.	EA
3A01151-063	Bulkhead Stn. #2	EA
3A01151-065	Bulkhead Stn. #5.6	EA
3A01151-067	Bulkhead Stn. #8.5	EA
3A01151-068	Bulkhead Stn. Step	EA
3A01151-071	Step Doubler, Amphib	EA
3A01151-073	Bulkhead Stn. #7.5 Btm.	EA
3A01156-003	Strip, Bottom Filler	EA
3A01156-004	Strip, Top Filler	EA
3A01156-007	Reinforcement, Spreader Bar Insp. Cover	EA
3A01156-007	Reinforcement, Spreader Bar Insp. Cover	EA
3A01156-050	Spacer, Hard Point Fwd.	EA
3A01156-050	Spacer, Hard Point Fwd.	EA
3A01156-051	Spacer, Hard Point Aft.	EA
3A01156-051	Spacer, Hard Point Aft.	EA
3A01158-001	Bulkhead, Wheel Well Lt.	EA
3A01158-002	Bulkhead, Wheel Well Rt.	EA
3A01158-043	Skin, Aft.	EA
3A01158-057	Skin, Wheel Well Lt./Rt.	EA
3A01158-058	Skin, Wheel Well Rt.	EA
3A01163-004	Unknown	EA
3A01339-001	Angle, Upright SPT Stn. #5.6Lt.	EA
3A01339-002	Angle, Upright SPT Stn. #5.6 Rt	EA
3A01339-003	Angle, Horiz. SPT Stn. #5.6	EA
3A01339-004	Angle, Sister Keel Attach Stn. #5.6	EA
3A01339-005	Angle, Sister Keel Attach Stn. #5.6	EA
3A01339-006	Angle, Upright SPT Stn. #6.5 Rt.	EA
3A01339-007	Angle, Upright SPT Stn. #6.5 Lt.	EA
3A01339-008	Angle, Sister Keel Attach Stn. #6.5	EA
3A01339-009	Angle, Sister Keel Attach Stn. #6.5	EA
3A01339-010	Bracket, Hyd. Pump Mount Upper	EA
3A01339-011	Angle, Main Keel Attach Step Stn	EA
3A01339-012	Angle, Main Keel Attach Step Stn.	EA
3A01339-013	Angle, Horiz. Support Lt.	EA
3A01339-014	Angle, Horiz. Support Rt.	EA
3A01339-016	Angle, Upright SPT Stn. #11.5 Rt.	EA
3A01339-017	Angle, Upright SPT Stn. #11.5 Lt.	EA
3A01339-018	Angle, Sister Keel Attach Stn. #11.5	EA
3A01339-019	Angle, Upright SPT Stn. #12.5 Lt.	EA
3A01339-020	Angle, Upright SPT Stn #12.5 Rt.	EA
3A01339-023	Sister Keel, Aft. Lt.	EA
3A01339-024	Sister Keel, Aft. Rt.	EA
3A01340-001	Angle, Support Stn. #2 Lt.	EA
3A01340-002	Angle, Support Stn. #2 Rt.	EA
3A01340-003	Angle, Support Stn. #4 Lt.	EA
3A01340-004	Angle, Support Stn. #4 Rt.	EA
3A01340-005	Angle, Main Keel Attach Stn. #6.5	EA
3A01340-006	Angle, Main Keel Attach Stn. #6.5	EA
3A01340-007	Angle, Support Stn. #8.5 Lt.	EA
3A01340-008	Angle, Support Stn. #8.5 Rt.	EA
3A01340-009	Angle, Main Keel Attach Stn. #5.6	EA
3A01340-010	Angle, Main Keel Attach Stn. #5.6	EA
3A01340-011	Angle, Main Keel Attach Stn. #7.5	EA

Part Number	Part Description	Unit of Measure
3A01340-012	Angle, Main Keel Attach Stn. #7.5	EA
3A01351-001	Chine, Fwd. Lt.	EA
3A01351-002	Chine, Fwd. Rt.	EA
3A01354-001	Keel, Main	EA
3A01357-027	Bracket, Hyd. Pump Mount Lower	EA
3A01357-028	Angle, Vert. Support Rt.	EA
3A01357-030	Angle, Trunion Attach Rt.	EA
3A01357-031	Angle, Trunion Attach Lt.	EA
3A01359-005	Angle, Nose Bumper Attach	EA
3A01363-001	Chine, Aft. Lt.	EA
3A01363-002	Chine, Aft. Rt.	EA
3A01366-001	Gunwall, Lt.	EA
3A01366-002	Gunwall, Rt.	EA
3A01618-001	Pumper Tube Stn. #1	EA
3A01618-002	Pumper Tube Stn. #2	EA
3A02000-015	Strut Assy. Aft. Left.(185)	EA
3A02000-015	Strut Assy. Aft. Left.(185)	EA
3A02000-016	Strut Assy. Aft. Right.(185)	EA
3A02000-016	Strut Assy. Aft. Right.(185)	EA
3a02350-01	Step	EA
3a02350-02	Step	EA
3A03001-001	Bracket, Pulley Mount Spreader Bar	EA
3A03001-001	Bracket, Pulley Mount Spreader Bar	EA
3A05000-001	Retractor Assy.	EA
3A05003-012	Frame, Rt.	EA
3A05003-013	Frame, Lt.	EA
3A05003-052	Brace, Retractor-Backside	EA
3A05061-001	Fork, Up Latch Release	EA
3A05158-004	Retainer, Magnet	EA
3S01002-016	Bulkhead Stn. #9 Straight	EA
3S01003-045	Support, Keel Main to Aft	EA
3S01156-002	Bulkhead Stn. #1	EA
3S01339-025	Sister Keel, Aft. Lt.	EA
3S01339-026	Sister Keel, Aft. Rt.	EA
3S01354-002	Keel, Main	EA
3S01728-001	Bumper-Nose, Modified	EA
4A01000-136	Bulkhead Assy. Stn. #4	EA
4A01000-137	Bulkhead Assy. Stn. #5	EA
4A01000-138	Bulkhead Assy. Stn. #6	EA
4A01000-140	Bulkhead Assy. Stn. #8	EA
4A01000-142	Bulkhead Assy. Stn #9	EA
4A01000-144	Bulkhead Assy. Stn. #10	EA
4A01000-145	Bulkhead Assy. Stn. #11 Left	EA
4A01000-147	Panel Assy. Wheel Well, Lt.	EA
4A01000-148	Panel Assy. Wheel Well, Rt.	EA
4A01000-150	Panel Assy. Spreader Bar Front Fwd.	EA
4A01000-151	Panel Assy. Spreader Bar Front Aft.	EA
4A01000-152	Panel Assy. Spreader Bar Mid. Fwd.	EA
4A01000-153	Panel Assy. Spreader Bar Rear Aft.	EA
4A01000-155	Cover Assy. #4	EA
4A01000-157	Wheel Well Side Assy. Lt.	EA
4A01000-158	Wheel Well Side Assy. Rt.	EA
4A01000-159	Bulkhead Assy. Stn. #1	EA

Part Number	Part Description	Unit of Measure
4A01000-171	Bulkhead Assy. Stn. #10 Left	EA
4A01000-172	Bulkhead Assy. Stn. #11 Right	EA
4A01000-215	Bulkhead Assy. Stn. #9	EA
4A01000-236	Baggage Floor Assy.	EA
4A01002-113	Doubler, Carrythru Strap Lt.	EA
4A01002-113	Doubler, Carrythru Strap Lt.	EA
4A01002-114	Doubler, Carrythru Strap Rt.	EA
4A01002-114	Doubler, Carrythru Strap Rt.	EA
4A01003-071	Carrythru Strap	EA
4A01004-073	Filler Strip-Side Doubler	EA
4A01005-194	Cover, Tunnel Fwd	EA
4A01005-195	Cover, Tunnel, Top Rear	EA
4A01005-200	Angel, Stn. #8 Aft. Outside Rt.	EA
4A01005-201	Angel, Stn. #8 Aft. Outside Lt.	EA
4A01005-202	Spacer, Nose Gusset	EA
4A01005-254	Sister Keel Web Stn. #5-8	EA
4A01008-086	Angle, Wheel Well Stn. #9	EA
4A01008-087	Angle, Carry Thru Strap	EA
4A01008-088	Angle, Stn. #8 Aft. Inside Rt.	EA
4A01008-089	Angle, Stn. #8 Aft. Inside Lt.	EA
4A01008-090	Doubler, Spreader Bar Hole SI	EA
4A01008-105	Spacer, Angle Top Deck Fitting	EA
4A01008-108	Angle,Sister Keel Station #8	EA
4A01008-109	Angle,Sister Keel Station #8	EA
4A01008-124	Angle, Carry Thru Strap Rt.	EA
4A01008-125	Angle, Carry Thru Strap Lt.	EA
4A01014-002	Spacer Boat Bracket	EA
4A01150-001	Stiffener, Bulkhead Stn. #12 Bottom	EA
4A01150-076	Bulkhead Stn. #4-1 Btm.	EA
4A01150-077	Bulkhead Stn. #4 Btm.	EA
4A01150-078	Bulkhead Stn. #6 Btm.	EA
4A01150-081	Bulkhead Stn. #7 Fwd. Btm.	EA
4A01150-082	Bulkhead Stn. #8 Aft. Btm.	EA
4A01150-083	Bulkhead Stn. #8 Fwd. Btm.	EA
4A01150-092	Angle, Wheel Well Rt.	EA
4A01150-093	Angle, Wheel Well Lt.	EA
4A01150-095	Bulkhead Stn. #3 Fwd. Btm.	EA
4A01150-096	Bulkhead Stn. #3-1 Aft. Btm.	EA
4A01150-097	Bulkhead Stn. #5 Fwd. Btm.	EA
4A01150-098	Bulkhead Stn. #5-1 Aft. Btm.	EA
4A01155-007	Strip-Filler, Top #12	EA
4A01155-008	Strip-Filler, Side, Btm. #12	EA
4A01155-009	Strip-Filler, Side, Btm. #12	EA
4A01155-012	Spacer, Top Skin Stiffener Fwd.	EA
4A01155-024	Spacer, Sister Keel	EA
4A01156-064	Panel, Spreader Bar Support-Bulk	EA
4A01156-065	Panel, Spreader Bar Support	EA
4A01156-066	Angle, Panel Bulk Stn. #8	EA
4A01156-067	Gusset, Side Nose	EA
4A01156-068	Gusset, Top Nose	EA
4a01156-075	Unknown	EA
4A01156-077	Panel-Spr.Bar Spt., Pulley Br same as 4A01156-064-065	EA
4A01157-004	Angle,Spacer, Sister Keel Attach	EA

Part Number	Part Description	Unit of Measure
4A01158-065	Bulkhead Stn. #2 Top	EA
4A01158-067	Bulkhead Stn. #7 Top	EA
4A01158-068	Bulkhead Stn. #8 Top	EA
4A01158-069	Bulkhead	EA
4A01158-074	Tunnel	EA
4A01158-083	Bulkhead Stn. #2 Btm.	EA
4A01158-089	Skin, Top Lt.	EA
4A01158-100	Bulkhead Stn. #9 Lower Panel (Old Style)	EA
4A01158-140	Bulkhead Stn. #9	EA
4A01160-013	Wheel Well Reinforcement	EA
4A01162-004	Baggage Lip	EA
4A01162-019	Doubler, Pulley Bracket Bulkhead Stn. #10	EA
4A01213-004	Ballard, (cleat, tie down)	EA
4A01300-001	Gusset, Sister Keel to Step BU	EA
4A01300-002	Gusset, Sister Keel to Step BU	EA
4A01330-001	Gunwall	EA
4A01330-002	Gunwall	EA
4A01331-001	Chine, Fwd. Lt.	EA
4A01331-002	Chine, Fwd. Rt.	EA
4A01332-001	Chine, Aft. Lt.	EA
4A01332-002	Chine, Aft. Rt.	EA
4A01339-048	Angle, Slide Tube Right	EA
4A01339-049	Angle, Slide Tube Left	EA
4A01339-050	Angle, Spreader Bar Panel Rt.	EA
4A01339-051	Angle, Spreader Bar Panel Lt.	EA
4A01339-052	Angle Support, Spreader Bar Panel Fwd.	EA
4A01339-053	Angle Support, Spreader Bar Panel Fwd.	EA
4A01339-054	Angle Support, Spreader Bar Panel Fwd.	EA
4A01339-055	Angle Support, Spreader Bar Panel Fwd.	EA
4A01339-056	Angle Support, Strut Mid.	EA
4A01339-057	Angle Support, & #8 BULK	EA
4A01339-058	Angle Support, Spreader Bar Aft.	EA
4A01339-059	Angle Support, Spreader Bar Aft. Lt.	EA
4A01339-062	Support Arm, Spreader Bar Panel Rt.	EA
4A01339-063	Support Arm, Spreader Bar Panel Lt.	EA
4A01340-029	Angle, Tunnel Lt. & Rt.	EA
4A01340-034	Bracket, Wheel Well Side Stn. #8	EA
4A01340-035	Angle, Bulkhead Stn. #12 Top	EA
4A01340-060	Stiffener-Side Vertical, Rt.	EA
4A01340-061	Stiffener-Side Vertical, Lt.	EA
4A01340-065	Stiffener-Side Vertical, Lt.	EA
4A01340-066	Stiffener-Side Vertical, Rt.	EA
4A01340-067	Stiffener-Side Vertical, Lt.	EA
4A01340-068	Stiffener-Side Vertical, Rt.	EA
4A01340-069	Stiffener-Side Vertical, Lt.	EA
4A01340-070	Stiffener-Side Vertical, Rt.	EA
4A01340-071	Stiffener-Side Vertical, Lt.	EA
4A01340-072	Stiffener-Side Vertical, Rt.	EA
4A01340-073	Stiffener-Side Vertical, Lt.	EA
4A01340-074	Stiffener-Side Vertical, Rt.	EA
4A01340-075	Stiffener-Side Vertical, Lt.	EA
4A01340-076	Stiffener-Side Vertical, Rt.	EA
4A01340-077	Stiffener-Side Vertical, Lt.	EA

Part Number	Part Description	Unit of Measure
4A01340-078	Stiffener-Side Vertical, Rt.	EA
4A01340-079	Stiffener-Side Vertical, Lt.	EA
4A01340-080	Stiffener-Side Vertical, Rt.	EA
4A01340-081	Stiffener-Side Vertical, Lt.	EA
4A01340-082	Stiffener-Side Vertical, Rt.	EA
4A01340-083	Stiffener-Side Vertical, Lt.	EA
4A01340-084	Stiffener-Side Vertical, Rt.	EA
4A01340-085	Stiffener-Side Vertical, Lt.	EA
4A01340-086	Stiffener-Side Vertical, Rt.	EA
4A01340-087	Stiffener-Side Vertical, Lt.	EA
4A01340-097	Stiffener, Sister Keel Web #5	EA
4A01340-098	Angle, Baggage Floor Stiffener	EA
4A01347-007	Keel, Aft.	EA
4A01348-007	Angle, Top Rail #10 & #11 Bulkhead	EA
4A01352-022	Angle, Skin Top Rt.	EA
4A01352-023	Angle, Skin Top Lt.	EA
4A01354-007	Keel, Main	EA
4A01357-042	Angle, Trunion Support	EA
4A01357-043	Angle, Trunion Support	EA
4A01357-044	Angle, Boat Bracket	EA
4A01359-094	Angle, Sister Keel Attach Stn. #	EA
4A01359-095	Angle, Sister Keel Attach Stn. #	EA
4A01359-096	Angle, Keel Attach Stn. #8 Rt.	EA
4A01359-097	Angle, Keel Attach Stn. #8 Lt.	EA
4A01359-098	Angle, Horiz. Top Stn. #8	EA
4A01359-099	Angle, Horiz. Btm. Stn. #8	EA
4A01359-100	Angle, Vert. Stn. #9 Rt.	EA
4A01359-100	Angle, Vert. Stn. #9 Rt.	EA
4A01359-101	Angle, Vert. Stn. #9 Lt.	EA
4A01359-102	Angle, Horiz. Stn. #9 Rt.	EA
4A01359-103	Angle, Sister Keel Attach Lt.	EA
4A01359-104	Angle, Sister Keel Attach Rt.	EA
4A01359-109	Angle, Nose Box Attach Stn. #2 Lt.	EA
4A01359-110	Angle, Nose Box Attach Stn. #2 Rt.	EA
4A01359-111	Angle, Wheel Well Lt.	EA
4A01359-112	Angle, Wheel Well Rt.	EA
4A01359-120	Angle, Stn. #12 Rt.	EA
4A01359-121	Angle, Stn. #12 Lt.	EA
4A01359-154	Angle, Sister Keel Attach Rt.	EA
4A01359-155	Angle, Sister Keel Attach Lt.	EA
4A01359-156	Angle, Main Keel Attach Rt.#3	EA
4A01359-157	Angle, Main Keel Attach Lt.#3	EA
4A01359-158	Angle, Sister Keel Attach Rt. #5	EA
4A01359-159	Angle, Sister Keel Attach Lt. #5	EA
4A01359-160	Angle, Main Keel Attach Rt.	EA
4A01427-006	Angle, Top Deck Fitting	EA
4A02000-087	Strut, Step Assy-Cargo, C-206/4000	EA
4A02000-231	Fitting Assy. Aft. Lt.(185)	EA
4A02062-003	Tongue, Strut Aft. Upper Fuselage (206)	EA
4A02160-026	Fitting, Firewall Doubler-Soloy	EA
4A02163-024	Doubler, Cargo Strut (206)	EA
4A02185-001	Fitting, Strut Lower Aft. (206)	EA
4A02185-002	Fitting, Strut Lower Mid. (185)	EA

Part Number	Part Description	Unit of Measure
4A02185-003	Fitting, Strut Lower Fwd. (185)	EA
4A02222-001	Fitting, Strut Float Deck	EA
4A02225-001	Fitting, Strut Upper Fwd. (206)	EA
4A02225-002	Fitting, Strut Lower Fwd. (206)	EA
4A02229-001	Fitting, Strut Lower Mid. (206)	EA
4A02263-005	Spacer, Strut Attach	EA
4A02333-001	Strut, Fwd. Left. (206)	EA
4A02333-002	Strut, Fwd. Right. (206)	EA
4A02333-003	Strut, Mid. Left. (206)	EA
4A02333-004	Strut, Mid. Right. (206)	EA
4A02333-005	Strut, Aft. Left. (206)	EA
4A02369-010	Step, Cargo (206)	EA
4A03335-001	Spreader Bar	EA
4A03390-001	Stub Spreader Bar	EA
4A03390-002	Spacer Support, Strut Mid.	EA
4A04086-002	Axle	EA
4A04189-005	Mount, Axle/Shock Strut	EA
4A04250-001	Piston Shock-Strut	EA
4A04251-001	Shock Strut, Top	EA
4A04258-005	Metering Pin-Shock Strut	EA
4A04273-005	Metering Tube, Shock-Strut	EA
4A04277-002	Base-Shock Strut Cylinder	EA
4A04528-002	Body, Shock Strut	EA
4A04529-002	Inner Cylinder Shock-Strut 4000	EA
4A05000-011	Assy,Ram, Main Gear 4000	EA
4A05116-004	Cylinder-Main Gear	EA
4A05402-005	Slide Tube	EA
4A06224-001	Pivot Block, Nose Gear	EA
4A06627-001	Spring, Nose Gear	EA
4A08000-068	Retract Handle Assy.-Water	EA
4A08000-073	Cable Assy. Steering Fuselage	EA
4A08000-076	Cable Assy. Balance Spreader Bar	EA
4A08000-077	Cable Assy. Balance Float	EA
4A08000-082	Cable Assy. Retract Handle	EA
4A08001-026	Blade-Water Rudder	EA
4A08011-004	Angle, Gunwall Pulley Attach	EA
4A12002-117	Spacer, Firewall (206)	EA
4S01000-173	Bulkhead Assy. Stn. #7	EA
4S01003-059	Carrythru Strap	EA
4S01004-055	Skin, Side Outboard Lt.	EA
4S01005-203	Angle, Stn. #8 Aft. Outside	EA
4S01005-204	Angle, Stn. #8 Aft. Outside	EA
4S01005-252	Web, Sister keel #7 #8 RH	EA
4S01005-253	Web, Sister Keel #7 #8 Lt.	EA
4S01008-094	Angle, Stn. #8 Aft. Inside	EA
4S01008-095	Angle, Stn. #8 Aft. Inside	EA
4S01158-092	Bulkhead Stn. #9 Body	EA
4S01158-096	Bulkhead Stn. #8 Top	EA
4S01158-119	Bulkhead Stn. #7 Top	EA
4S01158-252	Spacer,Shim Carry Thru Attach	EA
4S01340-096	Stiffener	EA
4S01354-008	Keel, Main	EA
4S01359-105	Angle, Keel Stn. #8	EA

Part Number	Part Description	Unit of Measure
4S01359-106	Angle, Sister Keel Rt.	EA
4S01359-107	Angle, Sister Keel Lt. Stn. #8	EA
4S01359-123	Angle, Keel Attach Stn. #8S	EA
6A02000-201	Fitting Strut Assy. Upper Left.	EA
6A02000-202	Fitting Strut Assy. Upper Right.	EA
6A02000-203	Fitting Strut Assy. Lower	EA
6A13002-200	Spar, Wing, Nose, Inboard, RH	EA
6A13002-201	Spar, Wing, Nose, Outboard, LH	EA
6A13002-202	Spar, Wing, Nose, Outboard, RH	EA
6A13002-203	Spar, Wing, Nose, Inboard, LH	EA
6A15004-162	Skin-Seat Top	EA
775804	Seal Kit, for 631875 valve	EA
77R6	Bearing, Ball & Roller, 3/8" DIA, MET Motor	EA
93270009-109	Strap Side Stiffener	EA
93270009-111	Angle	EA
93270016-101	Angle	EA
93270016-103	Access Panel	EA
93270016-105	Angle #14	EA
93270016-107	Joint Plate	EA
93270016-113	Angle #14	EA
93270016-115	Corner Splice	EA
93270018-101	Skin	EA
93270019-101	Doubler Mech Install	EA
93270020-111	Tee Stiffener	EA
93270020-115	Angle	EA
93270020-123	Reflector Shields	EA
93270020-159	Packing	EA
93270020-164	Side Channel	EA
93270020-171A	Vent Cover End	EA
93270020-175	Mid Packer	EA
93270020-187	Flanged Support Plate	EA
93270020-189	Packer	EA
93270020-191	Packer	EA
93270020-199	Bracket	EA
93270022-107	Collar Counter Sunk	EA
93270023-101	Gear	EA
93270024-101	Stiff Stud	EA
93270030-105	Spacer	EA
93270035-101	Stop Fitting	EA
93270039-103	Cover Access Hole	EA
93270041-101	Clip	EA
93270049-101	Support	EA
93270049-107	Sleeve	EA
93270052-105	Unknown	EA
93270053-101	Unknown	EA
93270054-101	Intermediate Bearing	EA
93270055-105	Tab Center Flanger	EA
93270055-109	Bottom Stiffener	EA
93270055-111	Angle #14	EA
93270055-112	Angle #14	EA
93270055-113	Angle #13/15	EA
93270055-115	Angle	EA
93270055-116	Angle	EA

Part Number	Part Description	Unit of Measure
93270055-121	Stiffener	EA
93270055-125	Inter Coatal #13	EA
93270059-103	Hinge Arm	EA
93270059-105	Hinge Arm	EA
93270061-101	Flute, Water Bomber Door	EA
93270061-102	Flute, Water Bomber Door	EA
93270062-101	Former Inboard	EA
93270062-102	Former Inboard	EA
93270063-101	Strap	EA
93270064-101	Angle	EA
93270064-103	Angle	EA
93270066-101	Unknown	EA
93270067-101	Closure Channel Inboard	EA
93270068-101	Bottom Skin Door 44	EA
93270075-101	Rod	EA
93270078-101	Shaft Collar	EA
93270080-106	Flute?	EA
93270080-107	Flute Bottom Water Bomber	EA
93270080-108	Flute Bottom Doubler	EA
93270080-109	Angle	EA
93270080-110	Angle	EA
93270080-113	U-Channel Center Support	EA
93270080-114	U-Channel Center Support	EA
93270080-115	Gusset,sister keel Area	EA
93270080-116	Gusset,sister keel Area	EA
93270080-125	Top Flange (Sides) #12	EA
93270080-127	Angle	EA
93270080-128	Angle	EA
93270080-129	Angle, #12	EA
93270080-130	Angle, #12	EA
93270080-131	Corner Cleat #12	EA
93270080-132	Corner Cleat #12	EA
93270080-133	Angle Sister Keel Area	EA
93270080-136	Clip # 12	EA
93270080-139	Top Flange (Middle) #12	EA
93270080-141	Spacer	EA
93270080-143	Splicer Plate #12	EA
93270080-145	Angle #12	EA
93270080-146	Angle #12	EA
93270080-149	Angle #12	EA
93270080-153	Angle #12	EA
93270080-155	Angle #12	EA
93270080-157	Corner Bracket Skin	EA
93270080-158	Corner Bracket Skin	EA
93270082-101	Closure Support FWD	EA
93270082-102	Closure Support AFT	EA
93270083-101	Closure Corners Outboard AFT	EA
93270083-102	Closure Corners Outboard FWD	EA
93270084-101	Closure Corners Inboard AFT	EA
93270084-102	Closure Corners Inboard FWD	EA
93270093-101	Tee	EA
93270094-101	Angle	EA
93270100-105	Bottom Flute, Super Panel Add-On	EA

Part Number	Part Description	Unit of Measure
93270100-106	Bottom Flute, Super Panel Add-On	EA
93270100-107	Cleat Super Panel Add-On	EA
93270100-108	Cleat Super Panel Add-On	EA
93270100-110	Bottom Flute, Super Panel Add-On	EA
93270100-111	Angle, Super Panel Add-On	EA
93270100-112	Angle, Super Panel Add-On	EA
93270100-117	Stiffener Super Panel Add-On	EA
93270100-118	Stiffener Super Panel Add-On	EA
93270100-119	Stiffener Super Panel Add-On	EA
93270100-120	Stiffener Super Panel Add-On	EA
93270100-121	Stiffener Super Panel Add-On	EA
93270100-123	Skin	EA
93270100-125	Angle Super Panel Add-On	EA
93270100-126	Angle Super Panel Add-On	EA
93270100-128	Angle Super Panel Add-On	EA
93270100-129	Angle Super Panel Add-On	EA
93270100-130	Angle Super Panel Add-On	EA
93270100-131	Angle Super Panel Add-On	EA
93270100-135	Corner Strap, Super Panel Add-On	EA
93270100-137	Packer	EA
93270100-143	Angle Super Panel Add-On	EA
93270100-145A	Angle Super Panel Add-On	EA
93270100-153	Angle	EA
93270100-154	Angle	EA
93270100-157	Sealing Angle	EA
93270100-158	Sealing Angle	EA
93270107-105	Side Plate	EA
93270108-102	Angle Vertical R #11	EA
93270108-105	Corner Gusset	EA
93270114-101	Inlet Flap	EA
93270117-001	Outer Throat Assembly	EA
93270118-102	Tee Support (Opposing)	EA
93270120-101	Latch Mounting Bracket	EA
93270121-101	Unknown	EA
93270121-102	Unknown	EA
93270121-105	Tunnel Chute Bulkhead	EA
93270121-113	Angle	EA
93270121-115	Channel Angle	EA
93270121-119	Channel Top	EA
93270121-119A	Channel Top	EA
93270121-125A	Splice Plate	EA
93270121-127	Angle	EA
93270121-127A	Angle	EA
93270121-129	Channel	EA
93270121-131	Splice Plate	EA
93270124-101	Plunger Door Indicator	EA
93270125-101	Flag Support Door Indicator	EA
93270126-003	Rod Door Flag	EA
93270127-101	Flad Mech Door Ind	EA
93270133-101	Tube Support Block	EA
93270157-101	Plate	EA
93270159-101	Probe Pivot Bracket	EA
93270163-001	Probe Assembly	EA

Part Number	Part Description	Unit of Measure
93270166-101	Side Doubler	EA
93270166-102	Side Doubler	EA
93270167-001	Front Strut Doubler	EA
93270167-153A	93270167-153A	EA
93270176-107	93270176-107	EA
93270176-108	93270176-108	EA
93270177-103	93270177-103	EA
93270177-104	93270177-104	EA
93270179-101	Angle	EA
93270209-101	Support Angle Guide Rod Top	EA
93270212-101	Spring Retainer	EA
AN3320-1	Relay, Stores Dropping Release	EA
AN676AC-5825	Flywire	EA
AN676AC-6656	Fly Wire	EA
AN832-6	Union, Flared Tube, 3/8 Bulkhead and Universal, 3/8" Tube DIA, 9/16-18 Thread, Steel	EA
AN832-8D	Union, Flared Tube, 3/8 Bulkhead and Universal, 1/2" Tube DIA, 3/4-16 Thread, Aluminum	EA
KD70119	Valve Kit	EA
RM332	Extru 6061T6 144in Long / Die 9604 4000	EA
RM354-1	Extru 6061T4 Main Keel 156in Long / Die 7443 When this is Gone use RM354	EA